

Compliance Notes

The Delta 810 may be connected to the following types of installation:

1. Direct Exchange Lines (DEL)
2. Compatible Private Automatic Branch Exchanges (PABX). Please contact the supplier of your Delta 810 to confirm compatibility with your PABX.

Whilst the Delta 810 is compliant as an extension to a compatible PABX system, it cannot be guaranteed to operate under all possible conditions of connection. Any case of difficulty should be referred in the first instance to the supplier of your telephone.

Guarantee

Your Delta 810 telephone is designed and manufactured to exacting quality standards. This enables ATL Telecom Limited to offer a 1 year guarantee from the date of purchase. This guarantee protects against faulty material or workmanship, applies to the UK only and is not transferable.

The terms and conditions under which the guarantee will be valid are as set out below.

1. Misuse or any modification carried out to the telephone, or operation other than in accordance with the instructions supplied, will invalidate the guarantee.
2. Damage arising from incorrect installation, accidental damage or consequential loss, are not covered under the guarantee.
3. In the event of a fault developing during the period of the guarantee, the complete telephone should be returned to your supplier, adequately and safely packed, together with proof of date of purchase.
4. The liability of ATL Telecom Limited will be limited to the cost of repair or complete replacement of the same defective instrument, at the discretion of the company. In the event that the same item is not available, a suitable alternative will be offered.
5. The terms of this guarantee do not affect your statutory rights.

Manufacturer's Declaration

ATL Telecom Limited declares that this product conforms with the essential requirements of the 'R&TTE directive 1999/5/EC'

Note: A copy of the Declaration of Conformity is available upon request from ATL Telecom Limited.

ATL Telecom Limited,
Lakeside,
Fountain Lane,
St Mellons,
Cardiff
CF3 0FB

Telephone: 0330 333 8250
Facsimile: 0330 333 8251



www.atltelecom.com
1/435/001/610

Issue 01

August 2013



Delta 810

Thank you for choosing the Delta 810 telephone. You have selected a carefully designed telephone that incorporates the very latest technology, offering a stylish instrument and providing many years of excellent service.

This booklet will ensure you obtain the best use of your telephone.



Delta 810

INITIAL CHECK

Our telephones are checked, tested and leave us in perfect condition. If yours is damaged, please return it to your supplier with proof of purchase, for a replacement.

CONNECTION

The Delta 810 telephone can be connected either to a Direct Exchange Line, or as an extension to a compatible company exchange (PABX).

HANDSET CORD

Connect the curly cable to the base of the handset.

LINECORD

The Delta 810 arrives with a linecord for connection to a standard BS6312 BT-socket. The line socket can be found on the underside of the base, plug your linecord into this port first and the other end into your telephone line termination point.

An RJ11 or an RJ45 linecord are available as an option, ask your supplier for details.

Using your Delta 810

RECEIVING CALLS

Incoming calls will be announced by the audible ringer. To answer the call, simply lift the handset.

ADJUSTING YOUR RINGER VOLUME

The ringer volume is controlled by a 3 position switch located at the bottom of the telephone keypad and indicated by a bell symbol.

MAKING A CALL VIA THE HANDSET

Pick up the handset and listen for dial tone

Dial the required telephone number

(Note: making external calls from a company exchange (PABX) may require the number to be prefixed by an access digit, normally '9')

Features and Facilities

TRANSFER KEY (RECALL / FLASH)

The Delta 810 telephone is provided with a 'TRANSFER' key, required by modern public and private exchanges, in order to gain access to various features such as 'transferring a call'.

REDIAL KEY

If you wish to redial the last number you dialled, you can do so by lifting the handset and pressing the 'REDIAL' button.

MUTE KEY

The microphone in the handset can be turned off (mute) Pressing and holding the 'MUTE' button turns off the microphone, releasing the 'MUTE' button turns the microphone back on.

RESET KEY

Pressing this key will terminate the current call and present the user with dial tone, ready to make another call

WALL MOUNTING

The phone can be wall mounted. The handset hook guide will need to be adjusted. This is achieved by sliding it upwards, rotated it by 180 degrees and returning it to its slot. The base of the phone can be secured to a suitable surface; screws should be 83mm apart.

Help

If the telephone appears to be faulty when first connected, a few simple checks may help to identify some possible problems, as listed below:

NO DIAL TONE

- Ensure you are using the cables that came with this phone.
- Check that the telephone plug is fully inserted in the socket
- If it is, try connecting the telephone into another socket, if available. If dial tone is now heard, the original socket is faulty.
- Alternatively, try connecting another telephone into your socket. If this telephone gives dial tone, then your new telephone is probably faulty.

Further concerns may also be addressed by calling our Technical Support Department on 0845 421 0730 or visiting our website, www.attelecom.com/support